



HANDLEBAR CUTTING INSTRUCTIONS

Thank you for purchasing your new Twisted Engineering Handlebar. Please read the following instructions entirely before cutting.

Warning: Use only the Twisted Engineering Handlebar cutting kit to prevent damaging the handlebar and voiding the warranty.

1. Determine final cut width. Remember if running T.E. Bark Guards to leave 3/8" extra per side (3/4" total) for the OD clamping ring.
2. Position and tighten the guide ring on the **inside** edge (towards triple clamp) of the cut line.
3. Install supplied hacksaw blade in your frame.
4. Using the **outside** edge of the guide ring as a guide, cut handlebar. Do not force hacksaw blade through material. With a smooth sawing action, cut through allowing the blade to do the work.
5. Remove guide ring.
6. Sand or file sharp edge removing all burrs.
7. Insert end plug
8. Repeat on opposite side.

1-88TWISTED-1

AEROSPACE INSPIRED, HIGH-PERFORMANCE HANDLEBARS,
THAT EXCEED EXPECTATIONS.